



Air Temperature Sensor

Part #'s 52-1217 thru 52-1224

5V maximum input voltage

32 cells are calculated, for 16 or 8 cell input, use every other, or fourth cell as necessary

F°	Ω
-10	1,590,308
20	546,977
40	288,325
60	159,661
80	92,373
95	62,885
110	43,686
125	30,922
140	22,268
155	16,296
170	12,104
185	9,115
200	6,954
215	5,369
230	4,193
245	3,308
260	2,637
275	2,121
290	1,721
305	1,408
320	1,161
335	964
350	806
365	678
380	574
395	489
410	419
425	361
440	312
455	272
470	237
485	208